

Product Specifications

Name	ChargeUp Boost 4th Generation 20K
Item Number	CY4750PBCHE, CY4751PBCHE, CY4752PBCHE, CY4753PBCHE
Battery Capacity	20,000mAh/74Wh
USB-C Input	5.0V—3.0A (15.0W)
Output(s)	USB-C Output: 5.0V—3.0A(15.0W) USB-A Output 1: 5.0V—3.0A(15.0W) USB-A Output 2: 5.0V—3.0A(15.0W)
Total Output	15.0W Max

Caution

Please read all warnings for your safety and optimal user experience. Please read and follow these instructions carefully and retain for your records.

- Do not disassemble or throw into fire or water.
- Do not microwave, incinerate, paint, or insert foreign objects into the power bank.
- Do not expose to extreme weather conditions.
- Do not use this product if you observe visible defects.
- Do not short circuit the product or store it in a receptacle where it may be short circuited by other metallic or conductive objects.
- Do not operate the product if it has been wet or otherwise damaged, to prevent against electric shock, explosion and or injury.
- Never attempt to dismantle the unit.
- Children should be supervised to ensure that they do not play with the product.
- Always disconnect the device when not in use.
- Do not use if broken, damaged, or exposed to liquids.
- Not to be used in extremely high ambient temperatures.
- Do not use with damaged or faulty accessories.
- Do not place near any sources of heat, open flame or liquid.
- Disposal of a battery into fire or a hot oven, mechanically crushing or cutting of a battery, can result in an explosion.

- Leaving a battery in an extremely high temperature can result in an explosion or the leakage of flammable liquid or gas.
- The power bank will generate heat when charging. Always charge in a well-ventilated area. Do not charge under pillows, blankets or on flammable surfaces.
- Do not subject the power bank to mechanical shock such as crushing, bending, puncturing or shredding. Avoid dropping or placing heavy objects on the power bank.
- Do not store the power bank without power to prevent the battery from being deeply over discharged, which may cause the battery bulge.
- Keep the power bank away from heat sources, direct sunlight, combustible gas, humidity, water, or other liquids.
- A battery subjected to extremely low air pressure may result in an explosion or the leakage of flammable liquid or gas.
- Operating temperature should be between 10°C to 45°C.

For all electrical products sold in the USA that undergoes FCC testing compliance, the following statement must be in the manual. 'Please note that changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to connect the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separate between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

Consult the dealer or an experienced radio/TV technician for help.

Cygnett and the Cygnett logo are trademarks of Cygnett Pty Ltd. Other brands and product names are trademarks or registered trademarks of their respective holders. Made in China.

Cygnett Pty Ltd
858 Lorimer Street, Port Melbourne,
Victoria, 3207, Australia

Cygnett USA Inc
3838 W Carson St, Ste 220,
Torrance, CA 90503

Cygnett NZ Ltd
Level 9, 45 Queen Street, Auckland 1010


Cygnett UK Ltd
71-75 Shelton St,
London, WC2H 9JQ

Cygnett EU Authorised Representative
24hour-AR
Van Nelleweg 1, 3044 BC Rotterdam,
The Netherlands
compliance@24hour-ar.com

CYGNETT®

ChargeUp Boost Power Bank 20K

User Manual




- A Power Button
- B LED Battery Indicator
- C USB-C Input/Output
- D USB-A Output 1
- E USB-A Output 2
- F Lanyard Hole

Charge Your Device

To ensure a proper charge it is important to plug the cables in the correct order.


Recharge your device(s) by first, connecting a compatible cable into the USB-C output (C) and/or USB-A output(s) (D/E) of the power bank and then the opposite end into your device(s). Press the power button (A), and your device(s) should begin to charge. When you are finished charging your device(s), remove the cables from your power bank, and it will turn off automatically.

To check the remaining charge on your power bank, press the power button (A) once. The LED battery indicator (B) will show the remaining charge from 0 to 100.



Recharge Your Power Bank


To recharge your power bank, use the included USB-A to USB-C cable, and connect the USB-A into a compatible USB-A charger, then insert the USB-C connector into the USB-C input (C). Alternatively, use a USB-C to USB-C cable and a USB-C charger. When recharging, the LED battery indicator (B) will flash, indicating the remaining charge.



After using the products power, charge it back up to at least 30% before turning off to ensure optimum battery life.

Installing the lanyard

To install the lanyard onto your power bank, feed the thin end of the lanyard through the lanyard hole (F), then feed the thick end through the loop of the thin end of the lanyard and pull tight.



Cable Management

To manage your cables with the power bank, bend the cable in half to create a loop, feed the loop through the lanyard hole (F), then feed the cable heads through the loop and pull tight.

