

Caution

1. The product is not a toy. Keep it away from children.
2. Do not disassemble or throw controller into fire or water.
3. Do not expose controller to extreme weather conditions.
4. Do not use the controller if you observe visible defects.
5. Do not short circuit the controller or store it in a receptacle where it may be short circuited by other metallic or conductive objects.
6. Do not operate the controller if it has been wet or otherwise damaged, to prevent against electric shock, explosion and/or injury.
7. Never attempt to dismantle the unit.
8. Children should be supervised to ensure that they do not play with the product.
9. Always disconnect the controller when not in charging.
10. Do not use if broken, damaged, or exposed to liquids.
11. Not to be used in extremely high ambient temperatures.
12. Do not use with damaged or faulty accessories.
13. Do not place near any sources of heat, open flame, or liquid.
14. Disposal the controller into fire or a hot oven, mechanically crushing or cutting of a battery, can result in an explosion.
15. Leaving the controller in an extremely high temperature can result in an explosion or the leakage of flammable liquid or gas.
16. The controller will generate heat when charging. Always charge in a well-ventilated area. Do not charge under pillows, blankets or on flammable surfaces.
17. Do not subject the controller to mechanical shock such as crushing, bending, puncturing, or shredding. Avoid dropping or placing heavy objects on the controller.

Cygnett takes no responsibility for damages caused by incorrect use of its products.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Warning: changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to connect the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.



This symbol on the product indicates that this product shall not be treated as household waste. Instead it shall be sent to the applicable collection point for the recycling of electronic equipment. By ensuring this product is disposed of correctly, you will help prevent potential negative consequences for the environment and human health. For more information about the recycling of this product, please contact your local city office.



WARNING: Cancer and Reproductive Harm – www.P65Warnings.ca.gov.



WARNING:

CHOKING HAZARD — Small parts not for children under 3 years or any individuals who have a tendency to place inedible objects in their mouths.


Cygnett and the Cygnett logo are trademarks of Cygnett Pty Ltd. Other brands and product names are trademarks or registered trademarks of their respective holders. Made in China.

Cygnett Pty Ltd 858 Lorimer St, Port Melbourne, Victoria 3207 Australia
Cygnett EU Authorised Representative 24hour-AR
Van Nelleweg 1, 3044 BC Rotterdam, The Netherlands
compliance@24hour-ar.com
Cygnett USA Inc 3838 W Carson St, Ste 220, Torrance, CA 90503
Cygnett UK Ltd 71-75 Shelton St, London, WC2H 9JQ
Cygnett NZ Ltd Level 9, 45 Queen Street, Auckland 1010

CYGNETT

GO-CREATE
SELFIE STICK

USER MANUAL



Installation Instructions

Applying your smartphone

Unfold the cradle section to the selfie stick (G), making sure that it is straight and in-line with the handle section (C). With two hands, separate the cradle section (G) to a point where you can easily fit your smartphone. Once applied, make sure the device is sitting centrally. Orientate device into the portrait or landscape positions as needed.

Extending the selfie stick

With two hands, grip both section in each hand (C & G) and slowly pull them apart from one another to begin extending to a length that is suitable. To close, simply reverse the process until closed.

Pairing your device with the controller

1. Switch button on the side of the remote to 'ON', and a light will flash blue. Then go to your smartphone's BT settings, ensure BT is turned on, and select for 'CY4474UNSES' when it appears.
A. iOS/Apple: Settings > BT > Turn BT on. It will automatically start searching for devices.
B. Android: Menu > Settings > Wireless & Network > BT settings > turn BT on by checking box. Then select 'Search for Devices'.
2. You're now ready to use the Selfie Stick. Use the corresponding shutter button on the remote to activate the shutter button. Compatible with Android 4.2.2 OS or newer and iOS 6.0 or newer. In the event of an incompatible version of Android OS, Cygnett recommends the Camera 360 Ultimate* app, available on Android and iOS platforms.

Turning controller on & off

Once paired with a device, press and hold the shutter button (A) for three (3) seconds to turn on or off. The LED will flash three (3) times in quick succession to indicate this has occurred. Please note, to re-apply the BT controller into the main body, you will have to slightly extend the shaft to allow enough clearance to replace it.

Installation Instructions Continued

Auto shut-down

After ten (10) minutes of no use, the BT controller will automatically turn off.

Product Specifications

Name	Go-Crete Selfie Stick
Item Number	CY4474UNSES CY4475COSBD
Battery Capacity	65mAh/0.24Wh
Input	Micro USB Input: 5.0V/0.1A (0.5W)
Working Frequency Band	2400-2483.5MHz
Max Output Power	57.1µV/m@10m (for EU)
FCC ID	2AEDZCY4474

Caution: Only recharge the BT Controller via a 5Vdc USB port or a 5Vdc, 0.5-1A Charger.